




2 Gimnasta



Piezas




Bloque N 2×13 (4)




Bloque N 2×5 (1)




Bloque N 3×11 (2)






Bloque N 3×5 (2)




Bloque 5×11 (2)



Engranaje básico (1)




03




x1 x4

04



x1 x4
x1 x4


05



x1 x1
x1


1:1

06




x1 x1
x1 x1

07





08




x1 x1 x1 x1



09



10





09




1:1



10



OK



¿Cómo hacer la conexión?



El cable rojo se conecta con +
El cable negro se conecta con -

