




# 3 | Motocicletă




## Piese



Bloc 11x17 (1)



Adaptor L 3x3 (2)



Bloc N 3x7 (1)



Bloc N 3x5 (3)



Adaptor L 3x4 (2)




Bloc N 1x11 (2)




Bloc N 2x5 (4)




Nit clasic (4)




Suport de motor (2)




Bloc triunghiular (2)




Bloc 3x5 (3)




Bloc 1x21 (2)




Bloc 1x11 (4)




Bloc de 45° (4)



Placă de bază MRT Card (1)



Bloc de îmbinare 1 (4)



Prelungitor (1)



Acumulator 1 (1)



M-shaft

Ax M (1)



Cauciuc roșu de ax (2)



Cablu de conectare (3)



Acumulator 2 (2)



Jantă 2 (2)



Anvelopă 2 (2)




Roată S (2)




Adaptor L (4)



Angrenaj L (1)



Senzor R/C (1)





LED G (1)





Motor 2 (2)



01





02



03




04







05




06




07




08



09



10



**11**

x1  
x2

**12**

x2

**13**

Notă: triunghiul roșu ▲ indică poziția.

x2  
x4

**14**

**15**

x2



**16**

M


1:1

x2  
x2  
x2  
x1  
x1



17




18




19






20



21





22










23






24





25





26




27



OK



## Cum se conectează?





# În practică



Programare:

1. Cycle start (all time)
2. Press the key ▲
3. Forward
4. LED 1 ON
5. Press the key ▼
6. Backward
7. LED 1 ON
8. Press the key ◀
9. Turn left
10. LED 1 ON
11. Press the key ▶
12. Turn right
13. LED 1 ON
14. Key off
15. Stop
16. LED 1 OFF
17. Cycle end



Press the key ▲



Press the key ▼



Press the key ◀




Press the key ▶



Key off



Forward



Backward



Stop



Turn left



Turn right




LED 1 ON



Cycle start (all time)



Cycle end



LED 1 OFF